



Key Switch Kit

Models: T7 / Speed Scrub Rider, R14, Strive Rider



NOTE: Key Switch 1016789 has been discontinued and replaced by this kit. This kit is intended for machines manufactured before date code 0908.

INSTALLATION INSTRUCTIONS:

Installation Time: 0.5 Hours

TOOLS REQUIRED: Phillips Screwdriver, 7/8" and 1" Wrenches

KIT CONTENTS

P/N	DESCRIPTION	QTY.
1011402	Switch, Key	1
1046313	Panel, Instmt, Rh	1
1014080	Gasket, Panl, Instmt, Rh	1

⚠ FOR SAFETY: Before installing kit, park machine on level surface, set parking brake, remove key and disconnect the positive (+) battery cable from batteries.

1. Remove the right side switch panel and remove the switches from the panel. Note the locations of all wire connections for re-installing later.
2. Attach the new gasket to the back of the new switch panel, then install the new key switch and re-install the horn, directional and emergency stop switches.
3. Mount the panel assembly to the console and test the switches for proper operation.

